

FA141075 - Ver. 2.0 - How to remove error for alarms not displaying in bottom of Citect page which is made by custom template.



## **How to remove error for alarms not displaying in bottom of Citect page which is made by custom template.**

This problem may occur due to the reason that there is conflict of the AN number. By default alarm template will take occupy AN 100, 101, 102 and in your project on some screens this AN 100, 101, 102 will be assigned to some other objects so on those pages alarms were not displayed. Kindly check those objects with AN 100, 101, 102 on the screen pages by using Control +G command and replace these objects with other AN number and then update pages. This will resolves your problem of alarm displaying.

[FA141075 | 2.0 | Published date: 21-Dec-2012](#)